

**SP336 PINOUT RECOMMENDATION FOR SINGLE DB-9 CONNECTOR**


**1.0 INTRODUCTION**

This document provides recommendations on how the SP336 can be used to support RS-232, half-duplex RS-485, and full-duplex RS-485/RS-422 on a single DB-9 connector.

**2.0 RS-232 PINOUT**

Figure 1 below shows the signals from the UART that are connected to the SP336. For RS-232, the DB-9 pins are defined. Since there are only 4 receivers on the SP336, the DSR signal from the DB-9 connector is not shown in the drawing. However, DSR can replace any of the other UART inputs that are not used.

**FIGURE 1. RS-232 PINOUT**




AN210

3.0 FULL-DUPLEX RS-485/RS-422 PINOUT

Figure 2 below shows which pins the full-duplex RS-485/RS-422 signals will be on the DB-9 connector when using the same UART connections shown in Figure 1. The RTS pin from the UART can be used to enable/disable the differential driver outputs.


FIGURE 2. FULL-DUPLEX RS-485/RS-422 PINOUT



**4.0 HALF-DUPLEX RS-485 PINOUT**

Figure 3 below shows the half-duplex RS-485 connections. The RTS pin is used to control the direction of the RS-485 differential drivers and receivers.

**FIGURE 3. HALF-DUPLEX RS-485 PINOUT**



**5.0 SUMMARY**

The tables below summarize the configurations in this document. Table 1 shows what the pin signals will be at the DB-9 connector.

**TABLE 1: DB-9 CONNECTOR PIN CONNECTIONS**

	DB-9 PIN 1	DB-9 PIN 2	DB-9 PIN 3	DB-9 PIN 4	DB-9 PIN 5	DB-9 PIN 6	DB-9 PIN 7	DB-9 PIN 8	DB-9 PIN 9
RS-232 Mode	DCD	RxD	TxD	DTR	GND		RTS	CTS	RI
RS-485/RS-422 Mode (Full-Duplex)		RX+	TX+		GND		TX-	RX-	
RS-485 Mode (Half-Duplex)			DATA+		GND		DATA-		
SP336 Pin Number	17	15	6	4	8		7	16	18

**AN210**

Table 2 shows the same information as table 1 but presented in a different way.

**TABLE 2: SP336 PIN CONNECTIONS**

	<b>SP336 PIN 4</b>	<b>SP336 PIN 6</b>	<b>SP336 PIN 7</b>	<b>SP336 PIN 8</b>	<b>SP336 PIN 15</b>	<b>SP336 PIN 16</b>	<b>SP336 PIN 17</b>	<b>SP336 PIN 18</b>
RS-232 Mode	DTR	TxD	RTS	GND	RxD	CTS	DCD	RI
RS-485/RS-422 Mode (Full-Duplex)		TX+	TX-	GND	RX+	RX-		
RS-485 Mode (Half-Duplex)		DATA+	DATA-	GND				
DB-9 Pin Number	4	3	7	5	2	8	1	9

**NOTICE**

EXAR Corporation reserves the right to make changes to the products contained in this publication in order to improve design, performance or reliability. EXAR Corporation assumes no responsibility for the use of any circuits described herein, conveys no license under any patent or other right, and makes no representation that the circuits are free of patent infringement. Charts and schedules contained here in are only for illustration purposes and may vary depending upon a user’s specific application. While the information in this publication has been carefully checked; no responsibility, however, is assumed for inaccuracies.

EXAR Corporation does not recommend the use of any of its products in life support applications where the failure or malfunction of the product can reasonably be expected to cause failure of the life support system or to significantly affect its safety or effectiveness. Products are not authorized for use in such applications unless EXAR Corporation receives, in writing, assurances to its satisfaction that: (a) the risk of injury or damage has been minimized; (b) the user assumes all such risks; (c) potential liability of EXAR Corporation is adequately protected under the circumstances.

Copyright 2011 EXAR Corporation

Document January 2011.

For technical support please email Exar’s Serial Technical Support group at: [serialtechsupport@exar.com](mailto:serialtechsupport@exar.com).

Reproduction, in part or whole, without the prior written consent of EXAR Corporation is prohibited.